



ORDER BY PART NUMBER, NOT CODE NUMBER

CODE NO.	PART NO.	NO. REQ	DESCRIPTION	CODE NO.	PART NO.	NO. REQ	DESCRIPTION
1	5032A	1	Stopper Assembly (Includes Code 2)	23	N/A	1	Sleeve
2	5029	1	Gasket, Stopper	24	71022	1	Shredder Assembly, Rotating
3	5170AC	1	Flange, Strainer	25	9209W	1	Upper End Bell Assembly
4	1160	1	Seal, Sink Flange	26	1470	1	Gasket, Tailpipe
5	5150E	1	Flange, Backup	27	8219	1	Tailpipe
6	5141	1	Flange, Mounting	28	5490	1	Flange, Tailpipe
7	5147	3	Screw, Backup	29	1491	1	Screw, Tailpipe
8	5166	1	Ring, Retaining	30	8629T	1	Stator Assembly
9	1010A	1	Gasket, Mounting	31	2642	1	Washer
10	5298	1	Flange, Body	32	70485	1	Rotor & Shaft Assembly (Includes Code 31)
11	71952	1	Cap, Trim Shell	33	2467	1	Centrifugal Actuator Assy
12	71788	3	Screw, Tapping	34	3706C	1	Switch Assembly, Start
13	9873	1	Body Container Assembly (Includes Codes 14)	35	2267CH	1	Overload, Protector
14	2539	1	O-Ring	36	4134	1	Shield, Wire
15	71965	1	Insulation	37	9901	1	End Frame Assembly, Lower (Includes Code 40)
16	72103C	1	Trim Shell, Assembly	38	71387	1	Cover, Terminal
17	71953	1	Wrench Holder	39	70734	1	Screw, Terminal Cover
18	70647	1	Sleeve & Seal Kit (Includes Codes 19 - 23)	40	2466A	1	Screw, Ground
19	2854	1	Plug	41	2486A	2	Bolt, Thru
20	N/A	1	Bolt, Hex Head Flange	42	72142	1	Use & Care Booklet
21	N/A	1	Slinger	43	2610SU	1	Instruction Assy (Not Shown) (Includes Codes 26-29 & 42)
22	N/A	1	Seal				